

Leather, DuraSoft and DuraFlect Collar Sizing Instructions

To determine the correct size leather, DuraSoft or DuraFlect collar for your dog, use one of the following procedures:

Measure your dog's neck with a sewing tape while keeping two fingers between his skin and the tape.

OR...

Wrap a string around your dogs neck with two fingers between his skin and the string. Then measure the length of the string.

OR...

Remove your dog's current collar and stretch it out flat. Then measure from the center of the buckle to the current sizing hole being used.



This measurement is your dog's neck size and the collar length to order.

Example: If you measured your dog's neck to be 16" and you want a 1" wide collar, you would order a 1"x16" collar.